

To order Tapping Valves specify:**Quantity**

If more than one size, specify quantity of each

Size

Nominal size of valve

Catalog number**Special catalog number suffix**

See chart at bottom of page 25 of the Gate Valve section if gearing, grease cases, by-pass valves or position indicators are required. The appropriate suffix number is added to the base catalog number.

Direction of opening

Specify open left (counter-clockwise) or open right (clockwise). Wrench nuts on valves that open to the right are painted red for identification purposes.

Method of operation

Non-rising valves are available with either a 2" square wrench nut or a handwheel. Handwheels are standard on flanged x flanged valves; all other NRS valves have a 2" square wrench nut as standard (24" through 48" also has bevel gearing). When ordering NRS valves, specify wrench nut or handwheel.

Special requirements

Contact Customer Support Center at 1-800-871-2194 with special requirements such as special paints or coatings, low zinc bronze stems, stainless steel fasteners etc.

Tapping Valve Repair Parts

To order repair parts specify size of valve, direction of opening, year date on body, catalog part number, catalog number of valve if known, and type of ends if ordering body.
